
crlaurence.com

CRL OVERHEAD TRACK BI-FOLD DOORS (OTB)

FULL PANEL OVERHEAD TRACK SYSTEM



CONTENTS

INTRODUCTION	02
CONFIGURATIONS	03
TOP TRACK INSTALLATION	04
RECESSED GUIDE CHANNEL AND PIVOT INSTALLATION	05
SURFACE MOUNTED TRACK AND PIVOT INSTALLATION	06
PIVOT DOOR LEAF ASSEMBLY	07
PIVOT DOOR LEAF INSTALLATION	08
SLIDING DOOR LEAF ASSEMBLY	09
SLIDING DOOR LEAF INSTALLATION	10
GLASS SIZING CHART	11

INTRODUCTION


Congratulations on your selection of the CRL Bi-Fold Door System. This system has been designed to work in a variety of applications. Ease of installation and adjustment for height and alignment by incorporating all the features of the CRL Wedge-Lock[®] Door Rail System make this your best choice in Overhead Track Bi-Fold Doors.

By following the instructions in this manual, we believe you will experience a trouble-free installation of the system. Should you have any questions about this system or any CRL product, please contact us at (800) 421-6144 or visit our web site at **crlaurence.com**.

IMPORTANT: PLEASE READ BEFORE INSTALLATION THE FOLLOWING INSTRUCTIONS WILL REDUCE YOUR CHANCES OF EXPERIENCING PROBLEMS DURING INSTALLATION, AND ENSURE SMOOTH, TROUBLE-FREE OPERATION OF THE PRODUCT

CONFIGURATIONS

Styles can be 2 panel Bi-Fold, 3 panel Bi-Fold, 4 Panel Bi-Parting Bi-Fold or 6 panel Bi-Parting Bi-Fold. The maximum width of each panel must not exceed 39" (990 mm) for 2 panel or 4 panel Bi-Part or 34" (863 mm) for 3 panel or 6 panel Bi-Part. Minimum panel width is 15" (381 mm). Maximum panel height 108" (2743 mm). Maximum weight per panel is not to exceed 170 lbs. (77 kg).



TOP TRACK INSTALLATION

- 1. The top track assembly is packed complete with top pivot, pivot block, and roller assemblies installed. Remove the top pivot(s) from the pivot block(s). This will expose the temporary screws holding the pivot blocks to the top track. Remove these screws and discard them. (Fig. 1)
- 2. Remove the roller assemblies by turning the roller assembly counter clockwise. (Fig. 2)
- 3. Secure the top track onto the top surface with #10 screws (not provided) at 12" (305 mm) on center and 1-1/2" (38 mm) from the wall. (Fig. 3)
- 4. Re-install the roller assemblies, and then secure the top pivot block, to the head with 1/4" (6 mm) screws (not provided). Screw lengths should be a minimum of 1" (25 mm). The head of the opening must be of sufficient strength to withstand considerable torque from the top hung panels when they are open.





Fig. 3

RECESSED GUIDE CHANNEL AND PIVOT INSTALLATION

- 1. The guide channel is set into the floor and is positioned directly under the center of the top track. (Fig. 4)
- 2. The bottom pivot is installed into the finished floor 2-3/4" (70 mm) from the wall and on the centerline of the guide channel. (Fig. 5)




OPTIONAL SURFACE MOUNTED SADDLE THRESHOLD AND PIVOT INSTALLATION

The **TH0T1** and **TH0T2** are optional surface mounted saddle thresholds that do not require notching of the floor substrate. They are factory machined at the pivot end but must be cut to length at the other.

CRL

- 1. The surface mounted saddle threshold is fastened with masonry screws at 12" (305 mm) on center and 3" (76 mm) from the wall onto the floor, positioned directly under the center of the top track. (Fig. 6)
- 2. The bottom pivot is installed onto the surface mounted saddle threshold 2-3/4" (70 mm) from the wall and on the centerline of the surface mounted saddle threshold. (Fig. 7)



CRL


PIVOT DOOR LEAF ASSEMBLY

TOP PIVOT RAIL

- 1. Remove both End Caps from the rail. (Fig. 8)
- 2. Remove the wool pile carrier from the rail. (Fig. 8)
- 3. Assemble the rail to the glass as directed in the rail assembly instructions included in the packaging.
- 4. Re-install the wool pile carrier.

BOTTOM PIVOT RAIL

- 1. Remove both End Caps from the rail. (Fig. 9)
- 2. Assemble the rail to the glass as directed in the rail assembly instructions included in the packaging.
- 3. Be sure that the bottom pivot is aligned with the top pivot in the top rail.



C.R. Laurence Co., Inc. • 2503 E. Vernon Ave., Los Angeles, CA 90058 • 1.800.421.6144 • crlaurence.com

PIVOT DOOR LEAF INSTALLATION

- 1. Lift the pivot door leaf and insert the pivot receiver on the door into the top pivot. (Fig. 10)
- 2. Raise the door leaf and slide it onto the bottom pivot. (Fig. 10)
- 3. Check the alignment with the head and jamb. If adjustment is required, follow procedures in the rail assembly instructions.
- 4. When the door leaf is aligned correctly, re-install the End Caps. (Fig. 11)




Fig. 10




Fig. 11

C.R. Laurence Co., Inc. • 2503 E. Vernon Ave., Los Angeles, CA 90058 • 1.800.421.6144 • crlaurence.com


SLIDING DOOR LEAF ASSEMBLY

SLIDER TOP RAIL

- 1. Remove both End Caps from the rail. (Fig. 12)
- 2. Remove the wool pile carrier from the rail. (Fig. 12)
- 3. Assemble the rail to the glass as directed in the rail assembly instructions included in the packaging.
- 4. Re-install the wool pile carrier.

SLIDER BOTTOM RAIL

- 1. Remove both End Caps from the rail. (Fig. 13)
- 2. Assemble the rail to the glass as directed in the rail assembly instructions included in the packaging.
- 3. Be sure that the bottom track guide is aligned with the anchor block in the top rail.



C.R. Laurence Co., Inc. • 2503 E. Vernon Ave., Los Angeles, CA 90058 • 1.800.421.6144 • crlaurence.com

SLIDING DOOR LEAF INSTALLATION

- 1. Lift the sliding door leaf and insert the bottom slide pin assembly on the door into the recessed guide channel or into the optional surface mounted saddle threshold. (Fig. 14)
- 2. Align the end of the top rail with the roller assembly block. Slide the roller assembly block into the top rail until it contacts with the anchor block. While maintaining contact, tighten the locking screw. (Fig. 15)
- 3. Secure the hinged end caps attached to the pivot door leaf to the sliding door leaf. Be sure the screws are tight. Continue this process until all the sliding door leaves are installed. (Fig. 16)
- 4. If height adjustment is required, rotate the height adjustment nut until the desired height is achieved. (Fig. 17)




Fig. 15






Fig. 16

FINAL ASSEMBLY

- 1. Check the operation of the door. If binding is observed when the door nears the full open position, <u>do not force.</u> This will be due to mis-alignment of the top or bottom pivot.
- 2. Release the hinged End Cap screws by a few turns and fully open the door. Any mis-alignment of the pivots will show as a gap between the hinge and the door rail.

CRL

- 3. Adjust the slides at the pivot end of the rail to bring the rails in line with the hinge and re-tighten the hinge screws.
- 4. Make any final adjustments to height and alignment. Install lock cylinders and any other hardware and check function.

GLASS SIZING CHART

OTB SYSTEMS GLASS WIDTH CALCULATOR 4" Height Top and Bottom Rails				
ОТВ		<u>GLASS WIDTH FORMULAS</u> FOR ALL SYSTEMS: GLASS WIDTH = PANEL WIDTH	MAXIMUM OPENING WIDTH	
	OTB2	$\left(\frac{\text{OPENING WIDTH}}{2}\right)$ - 3/16" (5mm)	78 - 3/8" (1.95 m)	
	ОТВЗ	$\left(\frac{\text{OPENING WIDTH}}{3}\right)$ - 3/16" (5mm)	102 - 9/16" (2.60 m)	
	ОТВ4ВР	$\left(\frac{\text{OPENING WIDTH}}{4}\right)$ - 3/16" (5mm)	156 - 3/4" (3.98 m)	
	ОТВ6ВР	$\left(\frac{\text{OPENING WIDTH}}{6}\right)$ - 3/16" (5mm)	205 - 1/8" (5.21 m)	

OTB SYSTEMS GLASS HEIGHT CALCULATOR 4" Height Top and Bottom Rails				
		GLASS HEIGHT FORMULAS		
	WITH RECESSED BOTTOM TRACK			
отв	WITH CLAD	OPENING HEIGHT MINUS 8-3/16" (208 mm)		
	WITHOUT CLAD	OPENING HEIGHT MINUS 8-1/8" (210 mm)		
	WITH SURFACE MOUNTED BOTTOM TRACK			
	WITH CLAD	OPENING HEIGHT MINUS 8-11/16" (220 mm)		
	WITHOUT CLAD	OPENING HEIGHT MINUS 8-5/8" (219 mm)		