

## Assembly Instructions

crlaurence.com

DECEMBER 2020

## SIX WHEELED FABRICATION CART (FC-48/82)



WEIGHT CAPACITY: 3,200 LBS.

*FC-48*: 48" x 28" x 47" / LOAD HEIGHT: 42" / WEIGHT:170 lbs. *FC-82*: 82" x 28" 73" / LOAD HEIGHT: 60" / WEIGHT: 253 lbs.

APPROXIMATE ASSEMBLY TIME: 15 MINUTES

- PARTS FOR ASSEMBLY: | TOOLS NEEDED:
- FC Base
- Caster Kit
- A-Frame
- Ratchet Straps
- 9/16" Wrench
- 11/16" Wrench
- 3/4" Wrench

- 1. Lay out base frame.
- Insert large wheels into the wheel supports and using two washers per wheel slide axle bolt through assembly and tighten nut.
- **3.** Attach casters using supplied bolts to the corners of the frame.
- **4.** Attach the uprights to the base frames using the supplied hardware, making sure to only finger tighten the nuts.
- 5. Install the cross braces leaving the hardware loose until all cross braces have been installed.
- 6. Go back and tighten all hardware.

## Safety Note:

Do not exceed weight or height capacities listed above.





## WHEN YOU RECEIVE YOUR SHIPMENTS, COMPARE NUMBER OF PIECES RECEIVED WITH YOUR PACKING LIST. IF FURTHER INFORMATION IS REQUIRED PLEASE CALL 800-421-6144 FOR ASSISTANCE.