



# MOUNTING INSTRUCTIONS:

1. PREPARE LOCK STILE PER TEMPLATE NO. 10-916 DRILL CYLINDER MOUNTING HOLES IF REQUIRED.
2. IF OUTSIDE TRIM IS BEING USED, FOLLOW DRILL TEMPLATE 10-997.
3. LOCATE CENTERLINE OF CYLINDER ON EXTERIOR OF DOOR AND DRILL IF REQUIRED.
4. TRIM TAIL PIECE TO FIT (3/16" PROJECTION FROM INSIDE FACE OF DOOR.)
5. MOUNT CYLINDER AND SECURE WITH MOUNTING SCREWS (SUPPLIED BY LOCK MFRG.)
6. TO LOCATE MOUNTING HOLE ON INACTIVE STILE DRILL & TAP 1/4-20 THDS. 38-5/32 FROM BTM. OF DOOR AND "L" DIM FROM ACTIVE STILE, AND INSTALL SHOULDER BOLT. TO INSTALL ACTIVE PAD INSTALL TWO SHOULDER BOLTS ON STILE.
7. MOUNT EXIT DEVICE AND TIGHTEN (3) 1/4-20 SOC. SET SCR'S. (2) ON ACTIVE PAD (1) ON INACTIVE END OF PANIC DEVICE.
8. TO INSTALL STRIKE LOCATE 10-24 TAPS ON ACTIVE STILE (2 PLACES).
9. MOUNT AND SECURE STRIKE.
10. CHECK OPERATION TO ASSURE THAT ALL PARTS INCLUDING CYLINDER IF BEING USED ARE FUNCTIONING PROPERLY.
11. **DOGGING INSTRUCTIONS**

TO DOG: :FULLY DEPRESS TOUCH BAR, PUSH DOGGING PIN, THEN RELEASE.  
TO UNDOG PUSH DOGGING PIN UP, BAR WILL RELEASE.  
12. WHEN ANTI-PICK CAM IS DEPRESSED BY STRIKE (BY HAVING DOOR CLOSED) LATCH WILL NOT RETRACT.

## MODEL 2095 LHRB (SHOWN)

FUNCTIONAL CYLINDERS	A	DOOR OPENING	"L"
ILCO	1/4" (6.35)	36" (914)	33-13/32" (848)
LOCKWOOD		42" (1066)	39-13/32" (1001)
YALE		48" (1219)	45-13/32" (1153)
CORBIN			
SCHLAGE			
RUSSWIN			
WELCH			
KEIL			
SARGENT	3/8" (9.53)		

C 06/12/00 ADD NOTES FOR OUTSIDE TRIM		ECN1384	RM
B 12/13/99 REDUCE "L" DIM BY 11/32		ECN1326	RM
DIMENSIONAL TOLERANCES UNLESS OTHERWISE SPECIFIED		APPROVED	DATE
DECIMAL DIMENSIONS .XXX ± .010	CHECKED		
DECIMAL DIMENSIONS .XXX ± .005	DRIVEN	RM	4/20/99
ANGULAR ± .5° FRACTIONAL ± 1/64	SCALE	NONE	
FILE NO. 10-917	MATERIAL	NONE	
NEXT ASSY. 2095-KITS	FINISH	NONE	
QTY. USED 1	HEAT TREAT	INSTALLATION GUIDE	
		2095 RIM DEVICE x "C" STRIKE	
		SHEET 1 OF 1 SHEETS	
		DWG. NO. 10-917	
		REV. C	

