Shower Door Installers Magnetic Alignment Tool CRL Cat. No. MAT1

The CRL MAT1 is another ingenious tool invented by a professional shower door installer as an aid to achieve faster, more efficient, and consistently higher quality installations.

The MAT1 includes two sets of powerful neodymium rare earth magnets, along with six pairs of steel spacers: 1/8" (3.2 mm), 3/16" (4.8 mm), and 1/4" (6.3 mm) thick by 3/8" (9.5 mm) and 1/2" (12.7 mm) wide. By applying a set at the top and bottom of any pair of shower panels, this selection allows precise gap alignment every time.

Simple to apply, just choose the appropriate pair of spacers for the glass thickness of your shower project. Apply spacer on the edge of one of the magnetic blocks. While holding this block from one side of the joint with the spacer between the panels, gently settle the second magnetic block onto the spacer from the opposite side. Once in place these powerful magnets will hold the spacer in position while a second assembly is attached to the other end of the joint. With both assemblies in place, adjust the panels snugly against the spacers to create a perfectly spaced and aligned gap between the panels.

Spacers are included for creating 1/8", 3/16", or 1/4" (3.2, 4.8, or 6.3 mm) gaps in 3/8" and 1/2" (10 and 12 mm) shower door panels. All MAT1 parts are sorted and supplied in a durable multi-compartment storage box.

