

## CRL Stud Mount Standoff Installation Steps

### STEP1



**Set and Fasten Stud to Wall**  
(Recommended to attach to a stud,  
anchor, or use a toggle bolt)

### STEP2



**Place Base onto Stud and  
Fasten with Allen Set Screw**

### STEP3



**Align Glass on Standoff**

### STEP4



**Insert Cap and Tighten with Cat. No. S0W Wrench**

**NOTE:** Due to the diversity of applications, weight limitations for Standoff Systems are dependent upon wall or substrate anchoring and material strengths.