



## **General Disclaimer and Maintenance Information for Latitude 34° Barn Doors**

---

### **General Disclaimer**

INSTALLATION: Latitude 34° barn door systems (Hemisphere, Meridian, Solstice) are to be safely installed by qualified glazing professionals with a comprehensive understanding of relevant products and site conditions. CRL is not responsible for the proper installation and resulting performance of the product(s), or the specification and performance of any other material or product used in conjunction.

Furthermore, CRL is not responsible for faulty site conditions, including but not limited to uneven floors or levels, walls being out of square or plumb, and improperly supported headers or other structural elements. Installer acknowledges that to deviate, or to not precisely follow all CRL provided specifications and installation instructions can result in unsafe or hazardous site conditions. Installer further acknowledges that improperly installed products are void of warranty and all CRL liability and obligations.

GLASS CONDITIONS: Any and all specifications and installation instructions provided by CRL for glass is only in respect to the installation of Latitude 34° barn door systems. It is the responsibility of the installer to determine and approve glass specifications suitable to meet CRL installation and performance guidelines.

### **Recommended Care & Maintenance**

1. Latitude 34° systems (Hemisphere, Meridian, Solstice) are intended solely for interior climate-controlled spaces. This includes before installation. Do not store the products in the sealed packaging that they are shipped in.
2. Thoroughly clean product and remove all debris and fingerprints immediately after installation using a dry non-abrasive lint-free cloth.
3. Periodically check tightness of all fasteners, particularly in high-use installations.

4. Periodically clean product using a dry non-abrasive lint-free cloth. DO NOT use abrasive tools of any kind.
5. Every few thousand cycles, use a clean and dry non-abrasive lint-free cloth to wipe all bearing and wheel-wearing surfaces to remove any buildup of dust or debris.
6. Keep product away from water and excessive moisture. If contact occurs, immediately wipe down surfaces with a clean and dry non-abrasive lint free cloth.
7. DO NOT use ammonia or chloride-based cleaners, alcohol or other solvents, or anaerobic thread lockers. Note that most glass and stainless steel cleaners contain chemicals that may damage the finish over time. Any cleaning solution must be checked for compatibility before being used on or near the product.
8. Select component parts are made of steel and may develop rust over time. To prevent this, regularly apply furniture style carnauba wax following the manufacturer's recommendations. Do not apply to plastic or rubber components.
9. Remember to only wipe down products using a clean and dry non-abrasive lint free cloth. DO NOT use any water, soaps, or other cleaning agents.

Improper product use, and/or not following CRL's outlined Care & Maintenance procedures, can greatly reduce functional product life. Site conditions such as UV exposure, dust, high humidity levels, and extreme temperatures can further reduce functional product life.