

Z-CLAMPS

MAXIMUM CLAMPING STRENGTH SEQUENCE



First, loosen the Flat Head Screws



Loosen enough so the Screw Heads project above the Clamp




Then slightly tighten the Allen Screw so the Plate tilts at a slant.



Lastly, secure the Flat Head Screws for Maximum Clamping Strength


Z-CLAMP INFORMATION

Minimum Grip - Allen Screw not engaged, clamping achieved by Tightening the Flat Head Screws Only.



Minimum Clamping Force

Maximum Grip - Allen Screw Slightly Engaged, so Cover Plate is Slightly Angled, Then Secure in Place by Tightening Flat Head Screws.



Maximum Clamping Force